

BJT MIXER FOR LOW SUPPLY VOLTAGE

BACKGROUND OF THE INVENTION

(1) *Field of the Invention*: This invention relates to analog mixers or multipliers, in particular, to electronic mixers or multipliers using bipolar transistors. Such mixers are used for multiplying two input signals or for converting two difference frequency signals into a beat frequency output.

(2) *Brief Description of Related Art*: In a conventional radio receiver, the incoming radio frequency is mixed with a local oscillator (LO) signal to produce a beat frequency, which is the intermediate frequency (IF). The IF is then amplified and filtered to attenuate other unwanted signals,

A popular mixer circuit is the differential pair or Gilbert multiplier. A bipolar transistor version of the Gilbert multiplier is shown in Fig.1. Basically, a differential amplifier with a differential pair Q2 and Q3 is fed from a current source Q1. The differential gain of the differential amplifier is proportional to the transconductance g_m of Q2 and Q3. This transconductance varies as the dc collector current of Q2 and Q3, which is controlled by the collector current of Q1. The dc collector current I_{C1} of Q1 is controlled by the dc base current V_{B1} of Q1. When a local oscillator signal V_{LO} of frequency f_{LO} is applied differentially to Q2 and Q3 (i.e. $V_{LO+} = V_{in-}/2$ and $V_{LO-} = V_{in+}/2$ respectively), and a radio frequency signal V_{rf} of frequency f_{rf} is applied to the base of Q1, the output current of the differential amplifier is equal to $V_{LO} * g_{m2}$, and the g_{m2} is proportional to $V_{rf} * g_{m1}$. When the V_{rf} is multiplied by V_{LO} , a beat frequency $f_{if} = f_{rf} \pm f_{LO}$ intermediate frequency signal V_{if} is produced.

While the Gilbert multiplier is widely used, it has a number of drawbacks for low voltage and low power applications. In modern integrated circuit technology, the tendency is to use a low supply voltage V_{CC} : for instance 25 V for 0.25 μm technology and 1.8 V for 0.18 μm technology. In the Gilbert mixer, the current source is operating in the active region of the V_{CE1} vs I_{C1} V-I characteristic Q1 in Fig.2 to obtain a higher transconductance and is proportional to V_{rf} . Therefore the dc collector voltage V_{C1} for the current source Q1 must not forward bias the collector junction, i.e. about the same as the dc base voltage ($\approx 0.7V$ for silicon BJT) to operate in the active region.

Similarly, the differential pair Q2 and Q3 also must have its collector voltage high enough to operate in the active region. Since the dc base voltage is about 0.7V higher than the emitter voltage of Q2 or V_{C1} ($\approx 0.7V$), the dc base voltage of Q2, hence the dc collector voltage, must be at least about $2 \times 0.7V$ or 1.4V. This voltage is higher than certain kind of battery voltage of 1.3 V.

If a resistor is used as a load, another voltage drop V_L will be added to be supplied by the power supply V_{CC} . These three stacks of voltages, V_{CE1} , V_{CE2} and V_L , dictate that the supply voltage cannot be made very low. For a typical base-to-emitter voltage of 0.7 V, there is hardly any “head room” for signal voltage swing. Besides, a higher supply voltage consume more power.

In U.S. Patent 6,388,501, Chien disclosed an MOSFET mixer operating at the knee of the drain V-I characteristics of the MOSFET. Since a MOSFET is gate voltage control device while a BJT is a base current control device and since the drain and source characteristics of a MOSFET are symmetrical but the collector and emitter characteristics of a BJT are not symmetrical, Chien's circuit is not applicable to a BJT mixer.

SUMMARY OF THE INVENTION

An object of this invention is to design a BJT mixer which requires a lower supply voltage than the Gilbert mixer or similar structure. Another object of this invention is to reduce the power consumption of the BJT mixer. Still another object of this invention is to provide a high conversion gain of the mixer. A further object of this invention is to set the operating point of the mixer at its optimum conversion gain automatically.

These objects are achieved by mixing the RF signal and the local oscillator signal at the knee of the output V_{CE} - I_C characteristic of a BJT as shown in Fig.2 with constant base current I_{B1} . At the knee, the characteristic has the sharpest curvature. The nonlinearity produces a maximum beat frequency signal. For implementation, a mixer BJT is biased at the knee of the V_{CE} - I_C characteristic. The LO (or RF) signal voltage V_{LO} (or V_{rf}) is applied at the base of the mixer BJT, and the RF (or LO) signal voltage V_{rf} (or V_{LO}) is injected at the collector of the mixer BJT. Then a beat frequency drain current is produced. Specifically, the gate of a single-ended mixer BJT is fed with a local oscillator signal and the collector of the mixer is dc coupled to a single-ended emitter follower with the base fed from a radio frequency signal or vise versa.

BRIEF DESCRIPTION OF THE SEVERAL VIEWS OF THE DRAWINGS

Fig.1 shows a prior art Gilbert BJT mixer.

Fig.2 shows the output V_{CE} - I_C characteristic of BJTs .

Fig.3 shows the basic mixer circuit of the present invention.

Fig.4 shows a tank circuit in series with the BJT mixer for deriving a beat frequency output.

Fig.5a shows a biasing circuit for automatically biasing the mixer BJT to the collector knee voltage using a BJT current mirror; and Fig.5b shows a MOSFET current mirror.

Fig. 6a shows a second embodiment of the biasing circuit using an ohmic base resistor to bias the emitter follower; Fig.6b shows a modification of Fig.6a.

Fig. 7 shows an inverted BJT mixer.

Fig.8 shows a parallel normal and inverted BJT mixer.

DETAILED DESCRIPTION OF THE INVENTION

Principle of Operation:

The basic circuit of the present invention is shown in Fig.3. Two NPN BJTs Q2 and Q1 are connected in series. The pull-down BJT Q1 has its emitter grounded and its collector C1 connected to the source of the pull-up BJT Q2. The drain C2 of Q2 is connected through a load R_L to the positive power supply V_{CC} . The RF voltage V_{rf} (V1) is ac coupled to the base of Q1, which is fed with a dc base current I_{B1} . The collector C1 of the Q1 is set at a quiescent voltage V_{knee} at the knee of the V_{CE} - I_C characteristic of Q1 as shown in Fig.2. The appropriate V_{knee} is set by applying the appropriate dc base current I_{B2} of Q2.

A LO signal voltage V_{LO} (V2) is ac coupled to the base of Q2, and an RF voltage V_{rf} (V1) is ac coupled to the base of Q1. At the knee of the V_{CE} - I_C characteristic of Q1, the V_{CE1} in saturation region is related to the dc collector current I_{C1} and the overdriving I_{B1} as follows:

$$V_{CE1} = V_T \ln \{ \alpha_1 (1 - I_{C1}/\beta_F I_{B1}) / [1 + (1 - \alpha_1) I_{C1}/I_{B1}] \} \quad (1)$$

where V_T is the thermal voltage q/kT (≈ 0.025 V at 27°C), α_1 is the inverse alpha, β_N is the normal β . Eq.1 neglects the ohmic resistance which may cause V_{CE1} to be somewhat higher.

Differentiate Eq.(1) with respect to V_{CE1} and transpose to obtain the slope of the V_{CE1} vs I_{C1} characteristics,

$$d(I_{C1}/I_{B1})/dV_{CE1} = -\alpha_1 [1 + (I_{C1}/I_{B1})(1 - \alpha_1 - 1/\beta_N) - (1 - \alpha_1)(I_{C1}/I_{B1})^2/\beta_N] / [1/\beta_N + (1 - \alpha_1)] \quad (3)$$

Differentiate Eq.(3) with respect to V_{CE1} again to get the second derivative,

$$d^2(I_{C1}/I_{B1})/dV_{CE1}^2 = [(1 - \alpha_1 - 1/\beta_N) - 2(I_{C1}/I_{B1})(1 - \alpha_1)/\beta_N] / [1/\beta_N + (1 - \alpha_1)] \quad (4)$$

Set Eq.(4) to zero to obtain the maximum curvature at the knee of the V_{CE1} vs I_{C1} characteristics,

$$(I_{C1}/I_{B1})_{knee} = [\beta_N - 1 / (1 - \alpha_1)] / 2 \quad (5)$$

Substitute Eq.(5) into Eq.(3) to obtain the maximum curvature,

$$[d(I_{C1}/I_{B1})/dV_{CE1}]_{max} = \{4\beta_N + (1 - \alpha_1)[\beta_N - 1 / (1 - \alpha_1)]^2\} / \{4 V_T [1/\beta_N + (1 - \alpha_1)]\} \quad (6)$$

When a signal V_{rf} is applied to the base of Q1, the signal superimposes an ac current on I_{C1} equal to

$$V_{rf} g_{m1} = V_{rf} I_{C1} / V_T \quad (7)$$

and the total collector current of Q1 becomes

$$I_{c1} = I_{C1}(1 + V_{rf}/V_T) \quad (8)$$

When an ac voltage V_{LO} is applied to the base of Q2 and since the voltage of the emitter follower is nearly equal to unity, the derivative

$$dV_{CE1} \approx V_{LO} \quad (9)$$

Substitute Eq. (8) into eq.(6) and multiply dV_{CE1} to obtain the output current,

$$dI_{C1} = [(z+1) I_{C1}(1+V_{rf}/V_T)][dV_{CE1}]/[2(z-1)V_T] \quad (10)$$

$$\text{where } z = \beta_N(1-\alpha_I) \quad (11)$$

The ac product output current is:

$$I_{out} = [(z+1)/2(z-1)]I_{C1} (V_{rf}V_{LO})/V_T^2 \quad (11)$$

which develops an output voltage V_{out} when a Load is connected the collector of Q2.

If $z \gg 1$,

$$I_{out} \approx I_{C1}(V_{rf}V_{LO})/(2V_T^2) \quad (12)$$

which can be proven to be the same as a Gilbert multiplier.

Thus, the product or conversion gain of this invention is no less than the Gilbert multiplier, but requires less dc supply voltage and hence less power dissipation.

Circuit Implementation:

The collector current I_{C1} is controlled by the base current I_{B2} and is equal to $\beta_2 I_{B2}$ of Q2. To bias the collector of Q1 to the proper knee of I_{C1} , the dc base current I_{B1} must be overdriven to satisfy Eq.(5), i.e. I_{B1} must be larger than I_{B2} for the same dc collector current I_{C1} .

In Fig.4, a parallel LC resonant tank circuit tuned to an intermediate frequency is connected as a load to the mixer to derive a beat frequency output voltage V_L .

A circuit to provide the proper base currents I_{B1} and I_{B2} is shown in Fig.5a. In this circuit, the base current I_{B1} is supplied from a current mirror comprising PNP transistors Q4 and Q5, which mirrors the base current of NPN transistor Q3. The dc emitter current of Q3 is controlled by the resistor R1 in series with the emitter of Q3, and collector of Q3 is connected to the positive power supply V_{CC} . The base current I_{B2} is supplied from another current mirror comprising PNP transistors Q7 and Q8, which the base current of NPN transistor Q6. The emitter current of Q6 is controlled by the resistor R2 in series with the emitter of Q6. The value of R2 should be such that the base current I_{B2} satisfies Eq. (5), which is less than I_{B1} . Then, the collector voltage V_{CE1} of Q1 is automatically biased to the knee of the collector characteristics. The input voltages V_1 (V_{rf}) and V_2 (V_{LO}) are capacitively

coupled to the bases of Q1 and Q2, respectively as shown in Fig.3 or Fig.4. These two voltages can be reversed without any difference to the conversion gain as shown in Eq.(12).

In Fig.5a, Q1 is saturated and V_{CE1} is typically less than 0.2V. The dc base voltage V_{2B} is typically V_{BE2} ($\approx 0.7V$) higher than its emitter voltage which is equal to V_{CE1} . Then, $V_{2B} = V_{CE1} + 0.7 V \geq 0.9V$. For the current mirror shown in Fig.5a, the current mirror Q3 should be in the active region, say $V_{CE3} \geq 0.3V$ below the supply voltage V_{CC} . Then the minimum supply voltage $V_{CC} \geq V_{CE1} + 0.7 + V_{CE3} \approx 1.2V$, which is lower than most single battery voltage. In this circuit, the PNP BJTs Q7 and Q8 can be replaced by two p-channel MOSFETs M7, M8; and the PNP BJTs Q4, Q5 be replaced by M4, M5 to serve as a similar current mirror, as shown in Fig.5b. By choosing the dc base current of Q1 to nearly twice that of Q2, the operating point is automatically set to the knee of the collector V_C - I_C characteristic.

If the base current I_{B2} of Q2 is fed through a resistor RB2 instead of the current mirror as shown in Fig.6a, the voltage drop across the resistor, say 0.1 V, can be less than the voltage drop of a current mirror. Then the required supply voltage $V_{CC} \geq V_{CE1} + V_{BE2} + V_{RB2} = 1.0V$ is even lower than that required in Fig.5a or Fig.5b. However, the required resistor RB2 is function of the current gain β of Q2, which may vary over a wide range. By operating Q2 as a current mirror of Q8 as shown in Fig.6b, the effective beta, hence the value of the resistor, can be fixed. The resistor RB2 can be a MOSFET operating in the ohmic region. Then the voltage drop V_{DS3} across the MOSFET or RB2 can be less than V_{CE3} in Fig.5a or Fig.5b, say 0.2 V. Thus, the required supply voltage becomes $V_{CC} \geq V_{CE1} + V_{BE2} + V_{DS3} = 1.0 V$ and is even lower than that required in Fig.5a or Fig.5b. It can be seen from Figs.5a, 5b and 6a, 6b that the required supply voltage V_{CC} is considerably lower than that required for the Gilbert multiplier or mixer.

Since the gain of the mixer is dependent upon the quantity $z [= \beta_N(1 - \alpha_I)]$ and the value of z may vary widely for different types of BJT with typically unsymmetrical collector and emitter characteristics, it may be sometimes more desirable to invert the mixer BJTs Q1' and Q2' as shown in Fig.7, or to connect a normal and an inverted BJTs in parallel as mixer BJTs Q1" and Q2" as shown Fig.8.

While the foregoing description employs NPN BJTs in Figs. 1- 8, it will be obvious that complementary PNP BJTs can be used by reversing the power supply. In the same token, the transistors used in the current mirrors in Figs. 5a, 5b and 6a, 6b can also be of complementary types.